

## 2015 JackRabbit® Full-Metal™ Application Guide

YEAR	MODEL	BED LENGTH	BOX	Kit Number
<b>CHEVY/ GMC</b>				
94-03	S-10/Sonoma	6'	SB	FMC0101
94-03	S-10/Sonoma	7' 4"	LB	FMC0202
04-14	Colorado/Canyon	6'	SB	FMC0646
04-14	Colorado/Canyon Crew Cab (*1)	5'	XSB	FMC3453
2015	Colorado/Canyon Crew Cab	5' 2"	XSB	FMCA03A25
2015	Colorado/Canyon	6' 2"	XSB	FMCA04A26
04-14	Silverado 1500 Crew Cab	5' 8"	XSB	FMC3250
04-14	Silverado HD 2500/3500 Dual Rear Wheel	8'	LB	FMC8569
88-13	C/K/Silverado, Heavy Duty^, & '14 Heavy Duty	6' 6"	SB	FMC0303
88-13	C/K/Silverado, Heavy Duty^, & '14 Heavy Duty	8'	LB	FMC0404
67-87	C/K Full-size***	6' 5"	SB	FMC1329
67-87	C/K Full-size***	8'	LB	FMC1204
88-06	Stepside**	6' 6"	SB	FMC2576
14-15	Silverado/Sierra 1500 & 2015 Heavy Duty	6' 6"	SB	FMC95A17
14-15	Silverado/Sierra 1500 & 2015 Heavy Duty	8'	LB	FMC9636
<b>WITH OPTIONAL CARGO MANAGEMENT SYSTEM TRACK</b>				
07-13	Silverado 1500 Crew Cab w/ CMS Track (*2)	5' 8"	XSB	FMC5670
07-13	Silverado & Heavy Duty w/ CMS Track (*2)	6' 6"	SB	FMC5468
07-13	Silverado & Heavy Duty w/ CMS Track (*2)	8'	LB	FMC5569
CMS = Cargo Management System				
<b>DODGE</b>				
87-11	Dakota****	6' 5"	SB	FMD0629
00-11	Dakota Quad Cab* (****)	5' 3"	XSB	FMD0606
94-01	Ram & '02 Ram 2500/3500	6' 5"	SB	FMD0777
94-01	Ram & '02 Ram 2500/3500	8' 1"	LB	FMD0890
02-08	Ram & '09 Ram 2500/3500	6' 2"	SB	FMD2233
02-08	Ram & '09 Ram 2500/3500	8'	LB	FMD2336
09-15	Ram	5' 6"	XSB	FMD77A01
09-15	Ram	6' 3"	SB	FMD7833
09-15	Ram	8'	LB	FMD7936
09-15	Ram w/Ram box	5' 6"	SB	FMD82A02
12-15	Ram w/Ram box	6' 4"	SB	FMD87A08
<b>FORD</b>				
93-05	Ranger Flareside/Splash	6'	SB	FMF0908
82-11	Ranger/Ranger STX	6'	SB	FMF1008
82-11	Ranger	7'	LB	FMF1109
73-96	F-Series	6' 8"	SB	FMF1310
66-96	F-Series	8'	LB	FMF1290
97-03	F-Series Light Duty & 2004 Heritage	6' 6"	SB	FMF0303
97-03	F-Series Light Duty & 2004 Heritage	8'	LB	FMF0404
04-14	F-Series LightDuty	6' 5"	SB	FMF2903
04-14	F-Series LightDuty	8'	LB	FMF3042
04-14	Super Crew / SuperCab	5' 6"	XSB	FMF2843
08-15	F-Series Super Duty	6' 9"	SB	FMF6985
08-15	F-Series Super Duty	8' 1"	LB	FMF7084
99-07	F-Series Super Duty	6' 9"	SB	FMF1410
99-07	F-Series Super Duty	8' 1"	LB	FMF1507
2015	F-Series LightDuty	6' 5"	SB	FMFA06A29
2015	F-Series LightDuty	8'	LB	FMFA07A30
2015	Super Crew / SuperCab	5' 6"	XSB	FMFA05A28
<b>HONDA</b>				
06-15	Ridgeline	5'	SB	FMH6082

## 2015 JackRabbit® Full-Metal™ Application Guide

YEAR	MODEL	BED LENGTH	BOX	Kit Number
<b>ISUZU</b>				
88-97	Pup	6' 1"	SB	FMI0601
88-97	King Cab	5' 11"	SB	FMI0608
97-00	Hombre	6' 1"	SB	FMI0101
05-10	I-350 Crew Cab	5'	XSB	N/A
05-10	I-280 Ext. Cab	6' 5"	SB	FMI0646
<b>MAZDA</b>				
94-10	B-Series	6'	SB	FMM1008
94-10	B-Series	7'	LB	FMM1109
<b>MITSUBISHI</b>				
06-10	Raider	5' 3"	SB	FMMI3958
<b>NISSAN</b>				
85-97	Truck	6' 1"	SB	FMN1001
85-97	Truck	7' 4"	LB	FMN1112
98-04	Frontier Reg Cab*	6' 4"	SB	FMN1137
98-04	Frontier King Cab	6'	SB	FMN1013
98-04	Frontier Crew Cab (*1)	5'	XSB	FMN3352
02-04	Frontier Crew Cab*	6' 2"	LB	FMN1013
05-15	Frontier King Cab*	6'	SB	FMN3857
05-15	Frontier Crew Cab (*2)	4' 10"	XSB	FMN5780
04-15	Titan King Cab (*2)	6' 7"	SB	FMN6793
04-15	Titan Crew Cab (*2)	5' 7"	XSB	FMN6894
04-15	Titan King Cab (*2)	8' 2"	LB	FMN6690
04-15	Titan Crew Cab (*2)	7' 3"	MB	FMN6591
<b>TOYOTA</b>				
95-04	Tacoma	6' 1"	SB	FMT0613
05-15	Tacoma Standard & Access Cabs (*3)	6' 2"	SB	FMT3554
05-15	Tacoma Double Cab (*2)	5' 1"	XSB	FMT7475
05-15	Tacoma Double Cab (*3)	6' 2"	LB	FMT3554
93-98	T-100 Ext Cab	6' 3"	SB	FMT1714
93-98	T-100	8' 1"	LB	FMT1890
99-06	Tundra	6' 2"	SB	FMT1714
01-06	Tundra	8'	LB	FMT1804
04-06	Tundra Double Cab	6' 2"	SB	FMT1748
07-15	Tundra Regular & Double Cab (*2)	6' 5"	SB	FMT5173
07-15	Tundra Regular & Double Cab (*2)	8'	LB	FMT5274
07-15	Tundra CrewMax (*2)	5' 5"	XSB	FMT5379

\* Tonneau cover impedes operation of OE Bed Extender option.

\*\* 88-06 Chevy Stepside requires drilling holes to mount Rails.

\*\*\* 67-87 Chevy C/K Fleetside requires additional Rail Shims; order part # TRPT1114-5

\*\*\*\* 08 Dodge Dakota requires removal of optional cargo management tie down bars.

(\*1) Raised Top Cover on the canister due to truck bed size.

(\*2) Will impede the use of the optional factory cargo management system

(\*3) Will require the removal of the front tie down hooks

^ Excludes composite box.

**Kits Ranked "E" and "S" are non stocking, special order kits and have a 2-3 week lead time**