



2015 BedLocker® W/Explorer Series™ Rails Application Guide

YEAR	MODEL	BED LENGTH	BOX	Kit Number
CHEVY/ GMC				
94-03	S-10/Sonoma	6'	SB	BEC0101
04-14	Colorado/Canyon	6'	SB	BEC0646
04-14	Colorado/Canyon Crew Cab	5'	XSB	N/A
04-15	Silverado 1500 Crew Cab	5' 8"	XSB	BEC3250
04-15	Silverado HD 2500/3500 Dual Rear Wheel	8'	LB	BEC8569
88-13	C/K/Silverado, Heavy Duty^, & '14 Heavy Duty	6' 5"	SB	BEC0303
88-13	C/K/Silverado, Heavy Duty^, & '14 Heavy Duty	8'	LB	BEC0404
67-87	C/K Full-size***	6' 5"	SB	BEC1329
67-87	C/K Full-size***	8'	LB	BEC1204
88-06	Stepside**	6' 6"	SB	BEC2576
14-15	Silverado/Sierra 1500 & 2015 Heavy Duty	6' 5"	SB	BEC95A17
14-15	Silverado/Sierra 1500 & 2015 Heavy Duty	8'	LB	BEC9636
WITH OPTIONAL CARGO MANAGEMENT SYSTEM TRACK				
07-13	Silverado 1500 Crew Cab w/ CMS Track (*2)	5' 8"	XSB	BEC5670
07-13	Silverado & Heavy Duty w/ CMS Track (*2)	6' 6"	SB	BEC5468
07-13	Silverado & Heavy Duty w/ CMS Track (*2)	8'	LB	BEC5569
CMS = Cargo Management System				
DODGE				
87-11	Dakota****	6' 5"	SB	BED0629
00-11	Dakota Quad Cab* (****)	5' 3"	XSB	BED0606
94-01	Ram & '02 Ram 2500/3500	6' 5"	SB	BED0777
94-01	Ram & '02 Ram 2500/3500	8' 1"	LB	BED0890
02-08	Ram & '09 Ram 2500/3500	6' 2"	SB	BED2233
02-08	Ram & '09 Ram 2500/3500	8'	LB	BED2336
09-15	Ram	5' 6"	XSB	BED77A01
09-15	Ram	6' 3"	SB	BED7833
09-15	Ram	8'	LB	BED7936
FORD				
93-05	Ranger Flareside/Splash	6'	SB	BEF0908
82-11	Ranger/Ranger STX	6'	SB	BEF1008
82-11	Ranger	7'	LB	BEF1109
73-96	F-Series	6' 8"	SB	BEF1310
66-96	F-Series	8'	LB	BEF1290
97-03	F-Series Light Duty & 2004 Heritage	6' 6"	SB	BEF0303
97-03	F-Series Light Duty & 2004 Heritage	8'	LB	BEF0404
04-13	F-Series LightDuty	6' 5"	SB	BEF2903
04-13	F-Series LightDuty	8'	LB	BEF3042
04-13	Super Crew / SuperCab	5' 6"	XSB	BEF2843
08-13	F-Series Super Duty	6' 9"	SB	BEF6985
08-13	F-Series Super Duty	8' 1"	LB	BEF7084
99-07	F-Series Super Duty	6' 9"	SB	BEF1410
99-07	F-Series Super Duty	8' 1"	LB	BEF1507
2015	F-Series LightDuty	6' 5"	SB	BEFA06A29
2015	F-Series LightDuty	8'	LB	BEFA07A30
2015	Super Crew / SuperCab	5' 6"	XSB	BEFA05A28



2015 BedLocker® W/Explorer Series™ Rails Application Guide

YEAR	MODEL	BED LENGTH	BOX	Kit Number
ISUZU				
88-97	Pup	6' 1"	SB	BEI0601
88-97	King Cab	5' 11"	SB	BEI0608
97-00	Hombre	6' 1"	SB	BEI0101
05-10	I-350 Crew Cab	5'	XSB	N/A
05-10	I-280 Ext. Cab	6' 5"	SB	BEI0646
MAZDA				
94-10	B-Series	6'	SB	BEM1008
NISSAN				
85-97	Truck	6' 1"	SB	BEN1001
85-97	Truck	7' 4"	LB	BEN1112
98-04	Frontier Reg Cab*	6' 4"	SB	BEN1137
98-04	Frontier King Cab	6'	SB	BEN1013
02-04	Frontier Crew Cab*	6' 2"	LB	BEN1013
05-15	Frontier King Cab*	6'	SB	N/A
05-15	Frontier Crew Cab (*2)	4' 10"	XSB	N/A
04-15	Titan King Cab (*2)	6' 7"	SB	BEN6793
04-15	Titan Crew Cab (*2)	5' 7"	XSB	BEN6894
04-15	Titan King Cab (*2)	8' 2"	LB	BEN6690
04-15	Titan Crew Cab (*2)	7' 3"	MB	BEN6591
TOYOTA				
95-04	Tacoma	6' 1"	SB	BET0613
05-15	Tacoma Standard & Access Cabs (*3)	6' 2"	SB	N/A
05-15	Tacoma Double Cab (*2)	5' 1"	XSB	N/A
05-15	Tacoma Double Cab (*3)	6' 2"	LB	N/A
93-98	T-100 Ext Cab	6' 3"	SB	BET1714
93-98	T-100	8' 1"	LB	BET1890
99-06	Tundra	6' 2"	SB	BET1714
01-06	Tundra	8'	LB	BET1804
04-06	Tundra Double Cab	6' 2"	SB	BET1748
07-15	Tundra Regular & Double Cab (*2)	6' 5"	SB	BET5173
07-15	Tundra Regular & Double Cab (*2)	8'	LB	BET5274
07-15	Tundra CrewMax (*2)	5' 5"	XSB	BET5379

* Tonneau cover impedes operation of OE Bed Extender option.

** 88-06 Chevy Stepside requires drilling holes to mount Rails.

*** 67-87 Chevy C/K Fleetside requires additional Rail Shims; order part # TRPT1114-5

**** 08 Dodge Dakota requires removal of optional cargo management tie down bars.

(*2) Will impede the use of the optional factory cargo management system

(*3) Will require the removal of the front tie down hooks

^ Excludes composite box.

Kits Ranked "E" and "S" are non stocking, special order kits and have a 2-3 week lead time