



2015 SWITCHBLADE® Application Guide

YEAR	MODEL	BED LENGTH	BOX	Kit Number
CHEVY/ GMC				
2015	Colorado/Canyon Crew Cab	5' 2"	XSB	SWCA03A25
2015	Colorado/Canyon	6' 2"	SB	SWCA04A26
88-13	C/K/Silverado, Heavy Duty^, & '14 Heavy Duty	6' 6"	SB	SWC0303
88-13	C/K/Silverado, Heavy Duty^, & '14 Heavy Duty	8'0"	LB	SWC0404
04-15	Silverado 1500 Crew Cab	5' 8"	XSB	SWC3250
14-15	Silverado/Sierra 1500 + 2015 Heavy Duty	6'6"	SB	SWC95A17
14-15	Silverado/Sierra 1500 + 2015 Heavy Duty	8'0"	LB	SWC96A18
DODGE				
09-15	Ram 1500 CREW CAB	5' 6"	XSB	SWD77A01
09-15	Ram	6' 3"	SB	SWD7833
09-15	Ram	8'0"	LB	SWD7936
02-08	Ram & '09 Ram 2500/3500	6' 2"	SB	SWD2233
02-08	Ram & '09 Ram 2500/3500	8'	LB	SWD2336
FORD				
04-14	Super Crew / SuperCab	5' 6"	XSB	SWF2843
97-14	F-Series LightDuty	6' 5"	SB	SWF29A20
97-14	F-Series LightDuty	8'	LB	SWF3042
08-14	F-Series Super Duty	6' 9"	SB	SWF6985
08-14	F-Series Super Duty	8' 1"	LB	SWF7084
2015	F-Series LightDuty	6' 5"	SB	SWFA06A29
2015	F-Series LightDuty	8'	LB	SWFA07A30
2015	Super Crew / SuperCab	5' 6"	XSB	SWFA05A28
TOYOTA				
07-15	Tundra CrewMax (*2)	5' 5"	XSB	SWT5379
07-15	Tundra Regular & Double Cab (*2)	6' 5"	SB	SWT5173
07-15	Tundra Regular & Double Cab (*2)	8'	LB	SWT5274
05-15	Tacoma Double Cab	5' 1"	XSB	SWT7475
05-15	Tacoma Regular and Access Cab	6' 2"	SB	SWT9854
NISSAN				
05-15	Nissan Frontier	4' 10"	XSB	SWN5780