



INSTALL. REMOVE. REPEAT.



- Install quickly and easily
- Remove just as easily for full bed access
- Retracts in seconds
- Solid-cover security
- Allows full rear visibility
- No bulky panels
- One-year warranty

SWITCHBLADE™

by



This brochure is based on the latest product information available at the time of publication. Pace Edwards reserves the right to make changes in standard features, prices, colors, materials, equipment, specifications and models at any time without notice or prior obligation. ©2014 Pace Edwards A division of Truck Accessories Group, L.L.C. All rights reserved 11/14. Part #SWB-FLYER





DESIGNED FOR EASY INSTALLATION AND REMOVAL, ANY TIME.

Switchblade is the ideal truck bed cover for people who want secure cargo space some of the time, and full-bed access the rest of the time. Not only are installation and removal fast, they require only a Phillips screwdriver and 7/16" wrench.

SWITCHBLADE™ KIT INCLUDES:

- Canister
- Two drain tubes
- Two side rails
- Two locator bolts
- Four screws
- Four rail clamps

INSTALLATION INSTRUCTIONS

1. Center canister on truck rails and push completely forward.
2. Position rail against the side of the truck's interior bed rail.
3. Slide clamps into the notches in the rail and tighten.
4. Tighten locator bolts.
5. Position the top cover on the canister and mount with four screws.

KIT CONTAINS

	YEAR	MODEL	BED LENGTH	BOX	COMPLETE KIT PART #	CANISTER PART #	RAIL PART #
CHEVY/ GMC	2015	Colorado/Canyon Crew Cab	5' 2"	XSB	SWCA03A25	SW2105	SW5125
	2015	Colorado/Canyon	6' 2"	SB	SWCA04A26	SW2104	SW5126
	88-13	C/K/Silverado, Heavy Duty [^] , & '14 Heavy Duty	6' 6"	SB	SWC0303	SW2003	SW5003
	88-13	C/K/Silverado, Heavy Duty [^] , & '14 Heavy Duty	8'0"	LB	SWC0404	SW2004	SW5004
	04-15	Silverado 1500 Crew Cab	5' 8"	XSB	SWC3250	SW2032	SW5050
	14-15	Silverado/Sierra 1500 + 2015 Heavy Duty	6'6"	SB	SWC95A17	SW2095	SW5117
	14-15	Silverado/Sierra 1500 + 2015 Heavy Duty	8'0"	LB	SWC96A18	SW2096	SW5118
DODGE	09-15	Ram 1500 CREW CAB	5' 6"	XSB	SWD77A01	SW2077	SW5101
	09-15	Ram	6' 3"	SB	SWD7833	SW2078	SW5033
	09-15	Ram	8'0"	LB	SWD7936	SW2079	SW5036
	02-08	Ram & '09 Ram 2500/3500	6' 2"	SB	SWD2233	SW2022	SW5033
	02-08	Ram & '09 Ram 2500/3500	8'	LB	SWD2336	SW2023	SW5036
FORD	04-14	Super Crew / SuperCab	5' 6"	XSB	SWF2843	SW2028	SW5043
	97-14	F-Series LightDuty	6' 5"	SB	SWF29A20	SW2029	SW5120
	97-14	F-Series LightDuty	8'	LB	SWF3042	SW2030	SW5042
	08-15	F-Series Super Duty	6' 9"	SB	SWF6985	SW2069	SW5085
	08-15	F-Series Super Duty	8' 1"	LB	SWF7084	SW2070	SW5084
	2015	F-Series LightDuty	6' 5"	SB	SWFA06A29	SW2106	SW5129
	2015	F-Series LightDuty	8'	LB	SWFA07A30	SW2107	SW5130
	2015	Super Crew / SuperCab	5' 6"	XSB	SWFA05A28	SW2105	SW5128
TOYOTA	07-15	Tundra CrewMax (*2)	5' 5"	XSB	SWT5379	SW2053	SW5079
	07-15	Tundra Regular & Double Cab (*2)	6' 5"	SB	SWT5173	SW2051	SW5073
	07-15	Tundra Regular & Double Cab (*2)	8'	LB	SWT5274	SW2052	SW5074
	05-15	Tacoma Double Cab	5' 1"	XSB	SWT7475	SW2074	SW5075
	05-15	Tacoma Regular and Access Cab	6' 2"	SB	SWT9854	SW2098	SW5054
NISSAN	05-15	Nissan Frontier	4' 10"	XSB	SWN5780	SW2057	SW5080

HD = Heavy Duty (*2) Will impede the use of the optional factory cargo management system ^ Excludes composite box