

## 2019 BedLocker® Application Guide

YEAR	MODEL	BOX LENGTH	BOX	KIT NUMBER
<b>CHEVY/ GMC</b>				
2019	Silverado 1500 Crew Cab	5' 8"	XSB	BLCA27A58
15-19	Colorado/Canyon Crew Cab	5' 2"	XSB	BLCA03A25
15-19	Colorado/Canyon	6' 2"	XSB	BLCA04A26
04-18	Silverado 1500 Crew Cab	5' 8"	XSB	BLC3250
14-18	Silverado/Sierra 1500 & 2015 HD - '19 GMC Sierra LIMITED	6' 6"	SB	BLC95A17
14-18	Silverado/Sierra 1500 & 2015 Heavy Duty	8'	LB	BLC9636
04-18	Silverado HD 2500/3500 Dual Rear Wheel	8'	LB	BLC8569
04-14	Colorado/Canyon	6'	SB	BLC0646
88-13	C/K/Silverado, Heavy Duty^, & '14 Heavy Duty	6' 6"	SB	BLC0303
88-13	C/K/Silverado, Heavy Duty^, & '14 Heavy Duty	8'	LB	BLC0404
88-06	Stepside**	6' 6"	SB	BLC2576
94-03	S-10/Sonoma	6'	SB	BLC0101
67-87	C/K Full-size***	6' 5"	SB	BLC1329
67-87	C/K Full-size***	8'	LB	BLC12A32
<b>WITH OPTIONAL CARGO MANAGEMENT SYSTEM TRACK</b>				
07-13	Silverado 1500 Crew Cab w/ CMS Track (*4)	5' 8"	XSB	BLC5670
04-14	Silverado & Heavy Duty w/ CMS Track (*4)	6' 6"	SB	BLC5468
07-13	Silverado & Heavy Duty w/ CMS Track (*4)	8'	LB	BLC5569
CMS = Cargo Management System				
<b>DODGE</b>				
2019	Ram	5' 7"	XSB	BLDA24A55
2019	Ram	6' 4"	SB	BLDA25A56
09-18	Ram	5' 6"	XSB	BLD77A01
09-18	Ram	6' 3"	SB	BLD7833
09-18	Ram	8'	LB	BLD7936
07-13	Ram w/Ram box	5' 6"	SB	BLD82A02
09-18	Ram w/Ram box	6' 4"	SB	BLD87A08
09-18	Ram & '09 Ram 2500/3500	6' 2"	SB	BLD2233
09-18	Ram & '09 Ram 2500/3500	8'	LB	BLD2336
09-18	Ram & '02 Ram 2500/3500	6' 5"	SB	BLD0777
12-18	Ram & '02 Ram 2500/3500	8' 1"	LB	BLD0890
02-08	Dakota Quad Cab* (****)	5' 3"	XSB	BLD0606
02-08	Dakota****	6' 5"	SB	BLD0629
<b>FORD</b>				
00-11	F-Series Super Duty	6' 9"	SB	BLFA18A44
87-11	F-Series Super Duty	8' 1"	LB	BLFA19A45
#N/A	Super Crew / SuperCab	5' 6"	XSB	BLFA05A28
#N/A	F-Series LightDuty	6' 5"	SB	BLFA06A29
17-19	F-Series LightDuty	8'	LB	BLFA07A30
17-19	F-Series Super Duty	6' 9"	SB	BLF6985
15-19	F-Series Super Duty	8' 1"	LB	BLF7084
15-19	Super Crew / SuperCab	5' 6"	XSB	BLF2843
15-19	F-Series LightDuty	6' 5"	SB	BLF2903
08-16	F-Series LightDuty	8'	LB	BLF3042
08-16	F-Series Super Duty	6' 9"	SB	BLF1410
04-14	F-Series Super Duty	8' 1"	LB	BLF1507
04-14	F-Series Light Duty & 2004 Heritage	6' 6"	SB	BLF0303
04-14	F-Series Light Duty & 2004 Heritage	8'	LB	BLF04A32
99-07	Ranger/Ranger STX	6'	SB	BLF1008
99-07	Ranger	7'	LB	BLF1109
97-03	Ranger Flareside/Splash	6'	SB	BLF0908
97-03	F-Series	6' 8"	SB	BLF1310
82-11	F-Series	8'	LB	BLF1290

<b>HONDA</b>				
73-96	Ridgeline	5'	SB	<b>BLHA17A43</b>
66-96	Ridgeline	5'	SB	<b>BLH6082</b>
<b>ISUZU</b>				
17-19	I-280 Ext. Cab	6'	SB	<b>BLI0646</b>
06-16	Hombre	6' 1"	SB	<b>BLI0101</b>
#N/A	Pup	6' 1"	SB	<b>BLI0601</b>
#N/A	King Cab	5' 11"	SB	<b>BLI0608</b>
<b>MAZDA</b>				
88-97	B-Series	6'	SB	<b>BLM1008</b>
88-97	B-Series	7'	LB	<b>BLM1109</b>
<b>MITSUBISHI</b>				
94-10	Raider	5' 3"	SB	<b>BLMI3958</b>
<b>NISSAN</b>				
#N/A	Titan Crew Cab (*1)	5' 6"	XSB	<b>BLNA14A40</b>
06-10	Titan King Cab (*1)	6'5"	SB	<b>BLNA15A41</b>
#N/A	Titan Single Cab (*1)	8' 1"	LB	<b>BLNA16A42</b>
#N/A	Frontier King Cab*	6'	SB	<b>BLN3857</b>
16-19	Frontier Crew Cab (*1)	4' 10"	XSB	<b>BLN5780</b>
16-19	Titan Crew Cab (*1)	5' 7"	XSB	<b>BLN6894</b>
16-19	Titan King Cab (*1)	6' 7"	SB	<b>BLN6793</b>
05-19	Titan Crew Cab (*1)	7' 3"	MB	<b>BLN6591</b>
05-19	Titan King Cab (*1)	8' 2"	LB	<b>BLN6690</b>
04-15	Frontier Crew Cab*	6'	SB	<b>BLN1013</b>
04-15	Frontier Reg Cab*	6' 4"	SB	<b>BLN1137</b>
04-15	Frontier King Cab	6'	SB	<b>BLN1013</b>
04-15	Truck	6' 1"	SB	<b>BLN1001</b>
98-04	Truck	7' 4"	LB	<b>BLN1112</b>
<b>TOYOTA</b>				
85-97	Tundra CrewMax (*2)	5' 5"	XSB	<b>BLT5379</b>
85-97	Tundra Regular & Double Cab (*2)	6' 5"	SB	<b>BLT5173</b>
#N/A	Tundra Regular & Double Cab (*2)	8'	LB	<b>BLT5274</b>
#N/A	Tacoma Double Cab (*2)	5' 1"	XSB	<b>BLTA10A38</b>
07-19	Tacoma Standard & Access Cabs (*3)	6' 2"	SB	<b>BLTA09A37</b>
07-19	Tacoma Double Cab (*2)	5' 1"	XSB	<b>BLT7475</b>
07-19	Tacoma Standard & Access Cabs (*3)	6' 2"	SB	<b>BLT3554</b>
16-19	Tacoma Double Cab (*3)	6' 2"	SB	<b>BLT3554</b>
16-19	Tundra Double Cab	6' 2"	SB	<b>BLT1748</b>
99-06	Tundra	6' 3"	SB	<b>BLT1714</b>
05-15	Tundra	8'	LB	<b>BLT18A32</b>
05-15	Tacoma	6' 1"	SB	<b>BLT0613</b>
04-06	T-100 Ext Cab	6' 3"	SB	<b>BLT1714</b>
93-98	T-100	8' 1"	LB	<b>BLT1890</b>

<b>BedLocker® Accessory Parts</b>	<b>Part #</b>
Manual Switch Kit	<b>BL-1120</b>

^ Excludes '01-02 Pro-Tec composite box

\* Tonneau cover impedes operation of OE Bed Extender option.

\*\* 88-06 Chevy Stepside requires drilling holes to mount Rails.

\*\*\*\* 08 Dodge Dakota requires removal of optional cargo management tie down bars.

(\*1) Will impede the use of the optional factory Utili-Track System

(\*2) Will impede the use of the optional factory Deck Rail System

(\*3) Will require the removal of the front tie down hooks

(\*4) Will impede the use of the optional factory cargo management system